

A futuristic digital scene with a blue and purple color palette. A hand is shown holding a glowing white bar. In the background, there is a city skyline and a globe. The Godrej logo is prominently displayed in the center, surrounded by digital lines and particles.

Godrej

The **Powerhouse**
that safeguard's India's
service industry



**COMMERCIAL & RELIGIOUS
ESTABLISHMENTS**

About Godrej Security Solutions

The undisputed leader in innovation and the most trusted in the Indian security industry, Godrej Security Solutions (GSS) consistently strives to surprise customers with path breaking security solutions. Keeping the customer needs at the forefront and backed by more than a century of experience and expertise, GSS has been at the helm of every breakthrough in the Indian security industry. Over the years, we've evolved from a safes manufacturer to a comprehensive security solutions provider offering hi-tech and intelligent technology driven products and services.

Today GSS exports to more than 55 countries worldwide and offers a wide range of security products that run the gamut from sturdy safes and world-class fire resistant solutions to advanced vault equipment and resilient strong room doors. With customer convenience being at the heart of all that we do, we offer solutions that go beyond the expected. We firmly believe it is these small moments that have the power to effect change. Take for instance, our next-gen safe deposit lockers that go the extra mile by offering complimentary accessories such as a log book and a handy magnetic light. Or for that matter, our range of automated safe deposit lockers that allow patrons to sit comfortably and summon their lockers at the swipe of a card. Precise innovations that comfort and assure customers only add to our credibility and elevates the trust in us. Even as you read this, our team of security experts are working hard and smart to invent new ways to harness technology and bring you tomorrow's products, today.

We believe in taking the first step into the future and that's what defines the Godrej legacy of stellar quality, exemplary service and unwavering trust.



COMMERCIAL ESTABLISHMENTS & RELIGIOUS ESTABLISHMENTS

Godrej Security Solutions is fully equipped to provide a full range of security solutions that suit various needs of Educational, Commercial, Religious and Hospitality spaces.

Workplace security and property safety assume greater significance in the daily operations of Office / Schools / Religious buildings. However, outdated, insufficient, or just inconvenient security installations are a big cause for concern for personnel, visitors, and office administrators alike. The need is for a reliable and efficient security solution provider to ensure convenience and flexibility along with security.

Solutions for Office Buildings provides advanced, intelligent product combinations on a lightweight management platform. The whole design unlocks the value of properties by adding security, efficiency and experience.

AI-empowered video security surveillance turns an installation into an impregnable fortress round the clock. Godrej Security Solution, with a wide range of offerings, helps users enjoy a safer and more enriching analytical experience at a cost which delivers reliability and performance via CMS. This tool enables school / Building administrators and staff to ensure safety as well as protect property from the risk of loss or theft.

The Powerhouse is committed to provide a reassuring environment with the help of comprehensive hardware architecture. In the process, build a safer and smarter world for today and tomorrow.

BENEFITS:

- Secure and smooth vehicle access.
- Simplified evidence collection and detailed vehicle records.
- Boosted operational efficiency via powerful remote control and statistics reports.
- Adapts to scenarios with or without attendant booths.

FEATURES:

- Automated access of registered vehicles by ANPR or card readers.
- Intelligent AI features enabling minute level monitoring.
- Different entry/exit rules for different groups of vehicles.
- On screen display of parking info and open spaces.

CCTV CAMERAS NVR - DVR - POE Surveillance System



Security is at the core of any life, every institution and a nation. Human surveillance comes with many limitations. At the same time, it's also neither practical nor feasible to employ a huge number of people merely for surveillance.

Godrej Security Solutions has cutting-edge solutions that take care of detecting trouble and also warn so that no harm is caused and preventive action can be initiated. Be it the smart Cameras/NVR with AI, the CMS for centralized monitoring, cameras that employ Edge-based analytics with intrusion alarm inputs, or specialized camera like ANPR, Hazard cameras that come armed with a hooter, or the next-gen SIM based solar camera, Fish eye camera and other intelligent cameras for Face and Intrusion detection with alerts, every security solution allows one to keep a watch on home, loved ones or any premise with ease. What's more, surveillance can be done remotely, without you even being there at the exact location. That's the power of futuristic technology from Godrej Security Solutions at your command. It not only makes life secure but also adds value to businesses and institutions.



STI-FB30IR4M-1080PS



STI-FD30IR4M-1080PAS



STI-VFB50IRM-1080PCS



STI-VFD30IRM-1080PCS



STI-VFB100IRM-1080PLPR



STI-FE30IR1.1M-4KAS



STI-NVR32S2-4K



ST-POE-16P2U1S

Features



Face Recognition or Capture



People Counting



Object Detection



Tripwire



Built-in Audio



Number Plate Recognition



Edge based Analytics



Vehicle / Pedestrian Detection



Health Monitoring



External Alarm Inputs

EAGLE-I NXT

Home Alarm System



The Eagle-I NXT system is latest generation alarm system that connects to the internet via WiFi or LAN cable, and also offers SMS backup. The Eagle-I NXT is safe, reliable and full of features that boost your security to a whole new level. The Eagle-I NXT offers a wide range of accessories that help you both secure your home and make your everyday life easier. It has all the expected security accessories, such as 2-way pet immune motion sensors, opening contacts for securing your doors and windows, smoke alarms, remote , vibration sensors, hooter cum stobe etc. All accessories are connected wirelessly to the Eagle-I NXT panel and have an industry-wide range between the accessories and the panel, which completely eliminates the need for signal boosters.

Features



Wi-Fi Enabled



Push Notifications and SMS



5 - Hour Standby*



100 dB Siren



Coverage up to 300 Mtr



Supports LAN Cable Connection



Supports GSM Card



Connect Remotely via App





SAFIRE KEYLOCK

Fire Resistant Home Locker

A contemporary fire resistant locker, it is designed to provide reliable protection to your important paper documents against fire.

Features



Fire-resistant
upto 60 mins



Certified and Tested at
RISE, Sweden / ECB-S



2-Key
Lock



FULL HEIGHT FLAP BARRIER

Touchless Access Control

Godrej's Full Height Flap Barrier offers the ideal contactless solution to control access to restricted areas. High on design, its elegant aesthetics take user comfort requirements into consideration.

Features

- ◆ Inline direct drive/ brushless DC motor based highly reliable drive.
- ◆ Alarm function in case of illegal intrusion and reverse intrusion.
- ◆ Short opening/ closing time less than 1.5 sec for high throughput flow.
- ◆ Simple integration with all access control systems.
- ◆ Automatic opening during power failure.
- ◆ Dynamic LED lane indication.
- ◆ Long life cycle and low operating cost.
- ◆ Tailgating detection with alarm.

SWING LANE FLAP BARRIER WITH FACE RECOGNITION SYSTEM

Godrej VigiGuard Swing Lane Flap Barrier with FRS is an extremely graceful, elegant and secured entry equipment designed to control pedestrians entering or exiting restricted areas. It provides an ideal contact less solution for admission and control with high aesthetic and comfort requirements. Designed for pedestrian entrance control, these turnstile gates open only for those with authorized access. It's anti-tailgating feature and crawling detection help detect unauthorized people and illegal intrusion.

Features

- ◆ Anti-tailgating feature to detect unauthorized people.
- ◆ Crawling detection to avoid illegal intrusion.
- ◆ DC brush-less motor based highly reliable drive.
- ◆ Alarm function in case of illegal intrusion and reverse intrusion.
- ◆ Short opening times in seconds for a high through flow.
- ◆ Automatic opening during power failure with battery backup.
- ◆ Long life cycle and low operation cost.
- ◆ Simple integration with all access control systems.

BLOCKING BOLLARDS

With the increase in illicit incidents using uncontrolled vehicles which can cause serious damage to life and property there is a need to lay special emphasis on security checks at sensitive places. To combat this possible threat, with the objective of thwarting unauthorized vehicular access, Godrej Security Solutions brings to you - Blocking Bollards, a modern and innovative deterrent. Vehicles are brought to a complete halt by the hydraulic bollard with no penetration onto site or past the impacted face of the unit. A key feature ensures that all forward energy is absorbed at the front of the equipment on impact.

Features

- ◆ Electro-hydraulically / Electro-pneumatically operated.
- ◆ Single or multiple units in row with one common drive unit.
- ◆ Crash rating: 350 kN to 926 kN (7500 kg vehicle to 80 kph).
- ◆ Loop detector provided for safety.
- ◆ Standard blocking height above surface level
- ◆ 600 / 700 / 800 / 1000 mm.
Diameter of Bollard: 220 mm & 275 mm.
- ◆ Hand pump for manual operation in case of power failure.
- ◆ Design certified and physically crash tested as per PAS68 standards.



POLE DETECTOR

GSCAN POLE Ferromagnetic Contraband Screener is a ferromagnetic metal detector for the detection of contrabands such as mobile phones, laptops, tablets, smart watches, guns, knives, razorblades and other threat items. It screens the complete body in a single walk-by for all ferro-magnetic sources. The system is simple and can be deployed within minutes and is ready to screen immediately.

Features

- ◆ Detects cell phones and ferrous contraband.
- ◆ Multizone detection for accurate pinpointing.
- ◆ Compact and light weight less than 10kg.
- ◆ Fully weatherproof IP 65 certified.
- ◆ Bluetooth headset for covert operation.
- ◆ Portables single pole type installation.
- ◆ Built-in battery backup of over 12 hrs.
- ◆ Weatherproof for outdoor use.
- ◆ Secure ease to use jog dial control.
- ◆ Password protection to prevent unauthorized access.



KEY MANAGEMENT

Key management system is a one-of-its-kind simple yet efficient security system to keep all your keys safe. Along with securing your keys, it prevents unauthorised access and guards all keys against theft or misplacement. Each key is attached to a smart-key or key fob which is individually identified and locked, allowing only authorised access. This is done using an RFID card or unique PIN codes or a combination of both. The LCD display meticulously traces every activity of the Key Management System and the electronic controllers grant authorised access. After each key transaction a record log is maintained using time stamp.

Features

- ◆ Computerised key control configures user rights and
- ◆ RFID cards as per the program.
- ◆ Key fitted to a smart key fob locks and identifies the
- ◆ keys using the built-in chip.
- ◆ No tagging required on key cabinet and any key can be placed in any slot, making it hassle free for the users.
- ◆ Automatically locks all key access battery or power failure.
- ◆ RFID Access to open front door for better security.
- ◆ Internal battery backup enables uninterrupted operation in the instance of power failure.
- ◆ Software has user-friendly interface for comprehensive monitoring of multiple key guards.
- ◆ Tamper alarm to alert in case of tampering or intrusion by an unauthorised user.



DOOR FRAME METAL DETECTOR

Godrej presents a thirty-three-zone walkthrough metal detector, with which each detection zone functions as an independent detector and automatically increases discrimination by reducing the cumulative signal effect caused by distributed harmless objects. It localizes a myriad of foreign objects including bullets, intraocular metallic fragments, swallowed coins, and other foreign bodies and medical devices.

Features



Access to programming protected by password



33 Zone metal detection for precise target location



Intelligent traffic counter



Reliable microprocessor based design



Built-in battery backup of over 12 hours



VALUMATIC Currency Counting Machine

Rely on the intelligent Godrej Valumatic to keep count of your currency notes with ease and accuracy. Engineered with double sided image processing technology, Godrej Valumatic currency counting machine authenticates currency, differentiates between denominations, counts them and calculates the total value. It features a TFT color LCD and a user-friendly interface for simplified operations, while increasing the overall efficiency of your business.

Features

- ◆ Full width Dual CIS (Contact Image Sensor) for high accuracy.
- ◆ Enhanced counterfeit detection through, UV, MG and IR sensors.
- ◆ Half note, Double note & Chain note detection. Batch and Add functions available.
- ◆ Easy upgrade via USB memory.
- ◆ Note Sr. No. and image capturing.
- ◆ 4 modes of operations:
 - MDC (Mix Denomination Counting).
 - SDC (Single Denomination Counting).
 - CNT (Counting Only, No Detection).
 - MULT (Multiple Currency Counting).



X-RAY BAGGAGE SCANNER

Godrej X-ray baggage scanner is an advanced dual energy X-ray inspection system and is perfectly suitable for all security and custom applications. The scanners are most popular due to their small footprint, ability to blend into building entrance environment and scan large volumes efficiently. These are commonly installed in airports, government buildings, corporate offices, transportation infrastructure etc. The optimised dual x ray generators and advanced propriety image processing algorithms provide the user with best-in-class high resolution image quality and excellent threat detection capability.

Features

- ◆ Tunnel sizes ranging from 50cmx30 cm to 100cmx100cm approx.
- ◆ Single generator 2D view, Single generator
- ◆ 3D (isometric view), Dual generator dual view options are available.
- ◆ Central supervisor console (Optional).
- ◆ Threat image projection feature (Optional).
- ◆ Accessories like stabilizer, rollers, CTPs etc are provided.
- ◆ Resolution: 42 SWG of wire.
- ◆ Penetration: 36 mm of steel.
- ◆ Anode Voltage: 160Kvp (Peak KV).
- ◆ Beam direction From bottom.
- ◆ Coloring: 3 color and 6 color based on atomic number signature Sealed oil cooling.



**The Powerhouse
is just
a call away!**



..... Customer Service



1800 209 5511
1800 209 9955



secare@godrej.com



Drop a 'Hi' on 9321665511



www.godrejsmartcare.com

SCAN



GODREJ SMART CARE

Disclaimer: In view of the Godrej policy of continuous development and improvement, the dimensions and specifications may be changed without prior notice or obligation. Colours of the products shown in this catalogue may not match the actual colour of the product due to printing limitations.

This product is designed and manufactured with recyclable material. At end of life of this product, you may recycle all the components. Alternatively, you may seek guidance for disposal at **1800 209 9955**.

ISO 9001:2015, ISO 14001:2015, ISO 45001:2018