

The Godrej logo is rendered in a glowing white cursive font, superimposed on a globe made of blue and white dots. The globe is set against a dark blue background with vertical lines of light and a city skyline silhouette at the bottom.

The **Powerhouse**  
that defends the nation



**HOMELAND SECURITY**

## *About Godrej Security Solutions*

**The undisputed leader** in innovation and the most trusted in the Indian security industry, Godrej Security Solutions (GSS) consistently strives to surprise customers with path breaking security solutions. Keeping the customer needs at the forefront and backed by more than a century of experience and expertise, GSS has been at the helm of every breakthrough in the Indian security industry. Over the years, we've evolved from a safes manufacturer to a comprehensive security solutions provider offering hi-tech and intelligent technology driven products and services.

Today GSS exports to more than 55 countries worldwide and offers a wide range of security products that run the gamut from sturdy safes and world-class fire resistant solutions to advanced vault equipment and resilient strong room doors. With customer convenience being at the heart of all that we do, we offer solutions that go beyond the expected. We firmly believe it is these small moments that have the power to effect change. Take for instance, our next-gen safe deposit lockers that go the extra mile by offering complimentary accessories such as a log book and a handy magnetic light. Or for that matter, our range of automated safe deposit lockers that allow patrons to sit comfortably and summon their lockers at the swipe of a card. Precise innovations that comfort and assure customers only add to our credibility and elevates the trust in us. Even as you read this, our team of security experts are working hard and smart to invent new ways to harness technology and bring you tomorrow's products, today.

**We believe in taking the first step into the future and that's what defines the Godrej legacy of stellar quality, exemplary service and unwavering trust.**



## **HOMELAND SECURITY**

Homeland Security consists of Internal Security (IS) and is looked after by the Ministry of Home Affairs (MHA). Currently, it encompasses an assortment of responsibilities from border management to internal securities. In between the spectrum would lie countering terrorism, a subject which currently has no dedicated department in the Ministry.

Presently the issue of Internal Security (IS) is being dealt with by a host of different ministries. These are: Ministry of Home Affairs (MHA), Ministry of Defence (MoD), Ministry of Law and Ministry of External Affairs (MEA). It's clear that the need for security is huge and it is absolutely imperative that no threat goes undetected and can possibly grow into a danger. Time has come for India to move out of its old archaic Constitutional structures and gear up to face the grave challenge posed by terrorism. All nations facing terrorist threat have revisited this aspect and evolved structure and mechanisms to suit their respective needs. Be it Land security or Air security through upcoming drone threats, there is a growing need to counter threat effectively and efficiently.

Trust the Powerhouse to be a more than able match for any threat perceptions. Godrej Security Solutions has a range of security solutions designed thoughtfully to keep our nation safe and secure.

# HANDHELD X-RAY IMAGER



Developed with focus on innovative technologies, X-ray handheld system is the highest surface penetrating handheld system that keeps the security forces safe and one step ahead of all times. Portable and superior image quality expedites the inspection process by allowing for quick scans and dispositioning of potential threats without compromising safety and security. More power equals better image performance with 140 keV and patented options, the handheld X-ray system sees through more material with greater depth.

## Features

- ◆ Patented wide infinity detector.
- ◆ X-ray shielding meets radiation safety standard.
- ◆ Deepest surface penetration in the market.
- ◆ Enhance image resolution.
- ◆ Lowest user radiation exposure.
- ◆ Left and right handed ergonomic operation.

# REAL TIME VIEWING SYSTEM



Real Time Viewing System is a unique, portable X-ray inspection system, with a mini-focus and micro-focus constant potential X-ray source.

## Features

- ◆ Dual energy option allows recognizing organic and inorganic objects.
- ◆ Micro-focus X-ray unit has a 30-micron focal spot.
- ◆ Obtained images can be stored in the control unit's memory (up to 30,000 image).
- ◆ The voltage can be adjusted from 20-160kV.
- ◆ Allows inspecting objects made from different materials with varying density and thickness.
- ◆ Inspects areas of an object in the detail, using geometric magnification (up to 40times).



## GROUND PENETRATING RADAR

The Ground Penetrating Radar is a three-sensor detector designed for detection of metal and metal-free mines and short wires. This instrument functions in 3 modes: Ground Penetrating Radar (GPR), Metal Detection (MD) and Wire Detection (WD).

### Features

- ◆ Detection of IEDs in both metal and plastic casings.
- ◆ Detection of short wires.
- ◆ Three modes - Ground Penetrating Radar (GPR), Metal Detection (MD) and Wire Detection (WD).
- ◆ Independent or simultaneous operation of GPR, MD and WD.
- ◆ Audio, visual and vibro signal.
- ◆ Ultra High Sensitivity.
- ◆ Selection of metal objects.
- ◆ Waterproof up to 1 m water depth (only search head).
- ◆ Soil compensation.
- ◆ Visual display readable during day and night.
- ◆ Lightweight, portable, foldable, resistant design.



## NON-LINEAR JUNCTION DETECTOR

Premises which are centres of sensitive information require a higher level of security. They have a greater need to surveillance equipment. Godrej Security Solutions 'Non-Linear Junction Detector, bridges that gap perfectly. It is a device that illuminates a small region of space with high-frequency, and is embedded with a detector that has a sensitive receiver tuned for these harmonics. Moreover, it provides appropriate displays to make the presence of these obscure items known to the user of the device.

### Features

- ◆ Detects almost any concealed electronics, whether the electronics are switched on or off.
- ◆ Generates a response at the 2D and 3D harmonics.
- ◆ A two-pronged security system.
- ◆ Equipped with high gain parabolic antenna (20 dB gain at 3600 MHz) and a laser.
- ◆ Equipped device weight 1 kg.
- ◆ Automatically transmit to a receiving frequency channel, which is free of noise and distortion.



# LIQUID EXPLOSIVE DETECTOR

Godrej Liquid Explosive Detector identify substances precisely, thanks to automatically obtaining the optimal focus point in milliseconds. It can detect the difference between the container and the actual substance, giving an improved measurement result. The autofocus makes it possible to detect and minimize fluorescence from containers. Serstech Arx is built on a modern software platform, putting usability and algorithms in focus. The brand new graphical user interface is easy to navigate and new features such as Guided Scan™ and the Quick Access™ feature make it possible to get precise results, faster.

## Features

- ◆ Autofocus - SharpEye™.
- ◆ New user interface.
- ◆ Wi-Fi.
- ◆ Create libraries and add your own substances.
- ◆ Quick and easy.
- ◆ No consumables, no maintenance cost.





# The Powerhouse is just a call away!



..... Customer Service .....



1800 209 5511  
1800 209 9955



[secare@godrej.com](mailto:secare@godrej.com)



Drop a 'Hi' on 9321665511



[www.godrejsmartcare.com](http://www.godrejsmartcare.com)

SCAN



## GODREJ SMART CARE

**Disclaimer:** In view of the Godrej policy of continuous development and improvement, the dimensions and specifications may be changed without prior notice or obligation. Colours of the products shown in this catalogue may not match the actual colour of the product due to printing limitations.

This product is designed and manufactured with recyclable material. At end of life of this product, you may recycle all the components. Alternatively, you may seek guidance for disposal at **1800 209 9955**.

ISO 9001:2015, ISO 14001:2015, ISO 45001:2018